# USA SPEC Application Guide

| Make | Model | Year | | iPod Interface | Cable for AUX/iPod | Visual ID | Notes — Update 11/11/08 |
|---|---|---|---|---|---|---|---|
| ***PA15-HON2 will not display TEXT for 07-09 Acura live-traffic Navi system.*** | | | | | | | |
| **Acura** | Integra | 92 - 01 | | PA11-HON | included | all models | Connector at radio |
| | Legend, Vigor | 91 - 97 | DF - HON | PA11-HON | included | all models | Pre-wired. Connector is in left-rear of trunk |
| | RL | 05 - 08 | | PA15-HON2 | included | Nav | No TEXT. |
| | | | | | | Non-Nav | TEXT. |
| | TL | 04 - 08 | | PA15-HON2 | included | Nav | No TEXT |
| | | | | | | Non-Nav | TEXT. |
| | MDX | 02 - 04 | DF - HON | PA11 HON | included | AM/FM/TAPE/CD RADIOS ONLY | |
| | MDX | 05 - 06 | | PA15-HON2 | included | all models | TEXT. |
| | MDX | 07 - 09* | | PA15-HON2 | included | Nav | No TEXT. *CallTech if the 07-09 MDX has RSE system. |
| | | | | | | Non-Nav | TEXT. *CallTech if the 07-09 MDX has RSE system. |
| | TSX | 04 - 08 | | PA15-HON2 | included | all models | TEXT on NON NAV RADIOS, No Text on NAV Radio |
| | TSX | 2009 | | PA15-HON2 | included | all models | Text on Non Nav Only with AM/FM/MP3 player. Does not work on Nav radio |
| | RDX | 07 - 09 | | PA15-HON2 | included | Nav | No TEXT |
| | | | | | | Non-Nav | TEXT. |
| | RSX Type-S | 02 - 06 | N/A | N/A | N/A | N/A | |
| | SLX | 98 - 00 | DF - TOY | PA15 TOY | included | all models | Connector at radio |
| ***Note: PA15-HON2y works with all types of radios including Nav, in-dash 6 disc changer, XM receiver and RSE system. For PA11-HON application, external CD changer must be disconnected.*** | | | | | | | |
| **Audi** | A4, Cabriolet | 98 - 02 | DF - VW | PA11 VW6 | CAS-AD3 | all models | 98-99: radio must have round PWR button in the middle. * Must order CAS-AD |
| | A4 | 03 - 07* | | PA11 VW6 | CAS-AD3 | all models | *SAT tuner needs to be disconnected if the vehicle has one. |
| | A6, A8 | 98 - 03 | DF - VW | PA11 VW6 | CAS-AD3 | all models | 13-pin connector in left-rear trunk. *must order CAS-AD. |
| | A6 | 03 - 07* | | PA11 VW6 | CAS-AD3 | all models | *SAT tuner needs to be disconnected if the vehicle has one. |
| | TT | 00 - 03 | DF - VW | PA11 VW6 | CAS-AD3 | all models | 13-pin connector behind the left-rear window panel. * Must order CAS-AD |
| ***Note: DF/PA12-BMW/PA12-BMWdsp are not compatible with vehicles with Nav sys. Satellite radio & external CD changer must be disconnected. Some later models of Z4, X3, and Mini may not have pre*** ***For radios with DSP button use PA12-BMW_dsp*** | | | | | | | |
| **BMW** | 3 Series | 96 - 05 | DF - BMW | PA12-BMW/dsp | included | all models | Pre-wired. Left-rear trunk. Except for vehicles with GPS system. Except 96 318Ti |
| | *Z3/Z4 | 99 - 07 | DF - BMW | PA12-BMW/dsp | included | all models | Pre-wired.Z3:Right-rear trunk.Z4:Rear compartment between rear spks |
| | 5 Series | 98 - 03 | DF - BMW | PA12-BMW/dsp | included | all models | Pre-wired. Left-rear trunk. Except vehicles with GPS. |
| | *X3/X5 | 99 - 07 | DF - BMW | PA12-BMW/dsp | included | all models | Except vehicles with GPS. Needs CAS-BMD cable if vehicle has DSP |
| | *Mini | 02 - 06 | DF - BMW | PA12-BMW/dsp | included | all models | Pre-wired. Right-rear trunk. |
| **Buick** | Rainer | 05 - 06 | | PA11 GM | included | band | |
| | Rendezvous | 04 - 06 | | PA11 GM | included | band | |
| | Lucerne | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Enclave | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| **Cadillac** | DTS | 06 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Escalade/EXT | 03 - 06 | SVG 707 | PA11 GM* | included | all models | *Use PA11-VETTE if the vehicle has XM and connect it @ XM (behind gloveBox) |
| | Escalade/EXT/EVS | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | *CTS/SRX | 04 - 07 | N/A | PA11 VETTE | included | all models | *Vehicles must have XM or Pre-wired cable for XM. Connect@XM Receiver. |
| **Chevrolet** | Camaro/Cavalier | 97 - 99 | | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected |
| | Camaro | 00 - 02 | | PA11 GM45 | included | aux button | 9-pin at radio or slave tape unit. Works with On-Star system. |
| | Impala/Monte Carlo | 97 - 99 | | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected |
| | Impala/Monte Carlo | 00 - 05 | DF GM | PA11 GM | included | aux or band button | Connector at radio. Radio must have AUX or Disc button |
| | Impala | 06 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Cobalt | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL11 needed if the vehicle DOES NOT have XM Receiver. |
| | HHR | 06 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL11 needed if the vehicle DOES NOT have XM Receiver. |
| | Malibu | 97 - 00 | | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected |
| | Malibu | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL11 needed if the vehicle DOES NOT have XM Receiver. |
| | Corvette | 05 - 09 | N/A | **PA11 VETTE | included | all models | **Vehicles must have XM or Pre-wired cable for XM. |
| **NOTE: pa11-gm45 will work with vehicles(97-99) with AM/FM/TAPE radios only. External CDP or/and CDC must be disconnected.** | | | | | | | |
| **Chevy Trucks** | Astro/Cargo Van | 97 - 01 | | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected |
| | Avalanche | 2002 | | PA11 GM45 | included | aux button | Connect behind the radio. |
| | Avalanche | 03 - 06 | | PA11 GM | included | aux/disc/band | Connector at radio. Radio must have band, AUX or Disc button |
| | Avalanche | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Blazer/S-10 Truck | 00 - 01 | | PA11 GM45 | included | aux button | 9-pin at radio or slave tape unit, works with On-Star system. |
| | *Blazer/S-10 Truck | 2004 | | PA11 GM | included | band | |
| | *Equinox | 05 - 06 | | PA11 VETTE | included | band | *Vehicles without XM requires CAS-GNOX cable (must order separately) |
| | Equinox | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | *SSR | 05 - 06 | | PA11 GM | included | band | |
| | *Trail Blazer | 04 - 09 | | PA11 GM | included | band | |
| | *Colorado | 05 - 09 | | PA11 GM | included | band | Only works with AM/FM/MP3 player |
| | Silverado | 00 - 02 | | PA11 GM45 | included | aux button | 9-pin at radio or slave tape unit, works with On-Star system. |
| | Silverado | 03 - 07* | | PA11 GM | included | aux/disc/band | *07 Classic only. Connector at radio. Radio must have band, AUX or Disc button |
| | Silverado | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | *Tahoe/Suburban* | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Tahoe/Suburban | 03 - 06 | | PA11 GM | included | aux/disc/band | Connector at radio. Radio must have band, AUX or Disc button |
| | Tahoe/Suburban | 97 - 99 | | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. |
| | Tahoe/Suburban | 00 - 02 | | PA11 GM45 | included | aux button | 9-pin at radio or slave tape unit, works with On-Star system. |
| | Traverse | 2009 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Venture | 03 - 04 | | PA11 GM | included | band | |
| | *Uplander | 05 - 07 | | PA11 VETTE | included | band | *Vehicles must have XM or Pre-wired cable for XM. |

| |
|---|
| **99 and earlier AM/FM/CD player will not control cd changer. 00-02 AM/FM/CD player will control cd changer and slave cassette.** |

# USA SPEC Application Guide

| Make | Model | Year | AUX Interface | iPod Interface | Cable for AUX/iPod | Visual ID | Notes Update 11/11/08 |
|---|---|---|---|---|---|---|---|
| ***Note: DF-CHR & PA11-CHR are not compatible with vehicles with Nav sys, satellite radio or DVD. External CD changer must be compatible.*** | | | | | | | |
| **Chrysler** | 300M, LHS | 02 - 04 | DF - CHR | PA11 CHR | included | mode button | 10-pin square plug at radio. |
| | 300M, LHS | 98 - 01 | DF - CHR | PA11 CHR | included | cd-c button | 8-pin din connector at radio. |
| | *300C* | *05 - 06* | *N/A* | | *included* | *Mode* | |
| | Concorde | 98 - 04 | DF - CHR | PA11 CHR | included | mode or CD-C | 10-pin square plug at radio. |
| | Concorde | 95 - 97 | DF - HON | PA11 HON | CDL - CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | Pacifica | 04 - 06 | DF - CHR | PA11 CHR | included | mode button | 10 pin square plug at radio. |
| | PT Cruiser | 01 - 05 | DF - CHR | PA11 CHR | included | mode or CD-C | 10-pin square plug at radio. |
| | *PT Cruiser* | *2006* | *N/A* | | *included* | *Mode* | |
| | Sebring / Cirrus | 01 - 06 | DF - CHR | PA11 CHR | included | mode or CD-C | 10-pin square plug at radio. |
| | Sebring / Cirrus | 95 - 00 | DF - HON | PA11 HON | CDL - CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | Town&Country/Voyager | 01 - 07 | DF - CHR | PA11 CHR | included | mode or CD-C | Except vehicles with OEM DVD system. |
| | Town&Country/Voyager | 95 - 00 | DF - HON | PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| ***Note: DF-CHR & PA11-CHR are not compatible with vehicles Nav sys, Satellite Radio, or DVD. External CD changer must be disconnected.*** | | | | | | | |
| **Dodge** | Caravan | 01 - 07 | DF - CHR | PA11 CHR | included | mode or CD-C | Except vehicles with OEM DVD system. |
| | Caravan | 95 - 00 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | *Dakota* | *04 - 07* | *N/A* | | *included* | *Mode* | |
| | Dakota | 01 - 03 | DF - CHR | PA11 CHR | included | mode or CD-C | Radio must have MODE or CD-C button. |
| | Dakota | 98 - 00 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | *Durango* | *04 - 07* | *N/A* | | *included* | *Mode* | |
| | Durango | 01 - 03 | DF - CHR | PA11 CHR | included | mode or CD-C | Radio must have MODE button. 10-pin square plug at radio. |
| | Durango | 95 - 00 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | Intrepid | 98 - 04 | DF - CHR | PA11 CHR | included | mode button | Radio must have MODE or CD-C button. |
| | Intrepid | 95 - 97 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | *Magnum* | *05 - 06* | *N/A* | | *included* | *Mode* | |
| | Neon | 00 - 05 | DF - CHR | PA11 CHR | included | mode or CD-C | Radio must have MODE or CD-C button. |
| | Neon | 95 - 99 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | Stratus | 01 - 06 | DF - CHR | PA11 CHR | included | mode or CD-C | Radio must have MODE or CD-C button. |
| | Stratus | 95 - 00 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle AM/FM/TAPE radio with MODE/CD |
| | *Ram* | *2006* | *N/A* | | *included* | *Mode* | |
| | Ram | 02 - 05 | DF - CHR | PA11 CHR | included | mode button | Radio must have MODE button. 10-pin square plug at radio. |
| | Ram | 95 - 01 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangle am/fm/tape radio with MODE/CD |
| **FORD/LINCOLN/MERCURY** | Continental/TownCar | 03 - 04 | DF - FORD20 | PA11 FORD1 | CAS F24 | cd button | CAS-F24 must be purchased separately. connect at the radio. |
| | | 98 - 02 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Cougar | 99 - 02 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | C.Victoria/G.Marquis | 03 - 05 | DF - FORD20 | PA11 FORD1 | CAS-F24 | cd button | *Use F20 cable for AM/FM/Tape radio, otherwise use F24 cable. |
| | | 98 - 02 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 96 - 97 | DF - FORD10/16 | PA11 FORD2 | included | cd button | *JBL or LUX audio system use F10 cable or PA10-FORD1/DF Ford10 |
| | Escape/Mustang | 04 - 08 | N/A | | | | |
| | Escape/Mustang | 01 - 03 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Econoline | 98 - 03 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 96 - 97 | DF - FORD16 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Excursion | 00 - 05 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Navigator | 04 - 05 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Expedition | 03 - 06 | | | included | | |
| | Expedition / Navigator | 99 - 02 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 96 - 98 | DF - FORD10/16 | PA11 FORD2 | included | cd button | *JBL or LUX audio system use F10 cable or PA10-FORD1/DF Ford10 |
| | Explorer/Mountaineer | 06 - 08 | N/A | | | | |
| | Explorer/Mountaineer | 98 - 05 | DF - FORD20 | PA11 FORD1 | included | disc button | Some 02-05 AM/FM CD players are not CDC control radios |
| | | 96 - 97 | DF - FORD10/16 | PA11 FORD2 | included | cd button | *JBL or LUX audio system use F10 cable or PA10-FORD1/DF Ford10 |
| | Edge/MKX | 07 - 08 | | | | | |
| | Focus | 00 - 02 | DF - FORD10 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 06 - 07 | | | | | |
| | Fusion/Milan/MKZ | 07 - 08 | | | | | |
| | F150 | 04 - 08 | N/A | | | | |
| | F-series Truck | 98 - 03 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 96 - 97 | DF - FORD16 | PA11 FORD2 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | F250/350 | 2004 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. No application for 2004-05 F150 |
| | F250/350 | 05 - 08 | N/A | | | | |
| | LS | 00 - 04 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | 500/Montego | 05 - 06 | N/A | | | | |
| | Marauder | 03 - 04 | DF - FORD20 | PA11 FORD1 | CAS-F24 | cd button | CAS-F24 must be puchased separately. Connect it behind the radio. |
| | Ranger PU | 98 - 04 | DF - FORD20 | PA11 FORD1 | included | cd button | Some 02-05 AM/FM CD players are not CDC control radios |
| | | 96 - 97 | DF - FORD16 | PA11 FORD2 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Sport Trac | 00 - 04 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | Taurus/Sable | 97 - 07 | DF - FORD10 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect at left rear trunk. |
| | Freestyle/Mariner | 05 - 06 | N/A | | | | |
| | Freestar/Monterey | 04 - 06 | N/A | | | | |
| | Windstar / Villager | 99 - 03 | DF - FORD20 | PA11 FORD1 | included | cd button | For CDC control radio only. Connect behind the radio. |
| | | 96 - 98 | DF - FORD16 | PA11 FORD2 | included | cd button | For CDC control radio only. Connect behind the radio. |

**** CAS-F14, CAS-F24 cables must be purchased separately**

**Note: Most of 2002 and up am/fm/cd player radios are not cdc control. All models If replacing an existing factory CDC use CAS-F14**

# USA SPEC Application Guide

| Make | Model | Year | AUX Interface | iPod Interface | Cable for AUX/iPod | Visual ID | Notes — Update 11/11/08 |
|---|---|---|---|---|---|---|---|
| ***NOTE: pa11-gm45 works with vehicles(97-99) with am/fm/tape radio only. External cdp and/or cdc must be disconnected.*** | | | | | | | |
| GMC | Acadia | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Sonoma | 2004 | DF - GM | PA11 - GM | included | band | |
| | Jimmy/Sonoma | 00 - 01 | N/A | PA11 GM45 | included | aux button | 9-pin plug at radio or at slave tape unit. OK with On-Star system. |
| | Safari/Cargo Van | 97 - 01 | N/A | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave CD must be disconnected. |
| | Canyon | 05 - 09 | N/A | *PA11 - GM | included | aux/disc/band | *only works with AM/FM/MP3 Player |
| | Sierra | 00 - 02 | N/A | PA11 GM45 | included | aux button | 9-pin plug at radio or slave tape unit. OK with On-Star system. |
| | Sierra | 03 - 07* | SVG 707 | PA11 - GM | included | aux/disc/band | *07Classic only. Connector at radio. Radio must have AUX or Disc button. |
| | Sierra | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Yukon/Denali | 07 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Yukon/Denali | 03 - 06 | SVG 707 | PA11 - GM | included | aux/disc/band | Connector at radio. Radio must have AUX or Disc button. |
| | Yukon/Denali | 00 - 02 | N/A | PA11 GM45 | included | aux button | Compatible with On-Star system. |
| | Envoy | 04 - 08 | SVG 707 | PA11 - GM | included | band | |
| **99 and earlier AM/FM/CD player will not control cd changer. 00-02 AM/FM/CD player will control CD changer and slave cassette.** | | | | | | | |
| Honda | Element | 03 - 09 | N/A | PA15 HON2 | included | all models | Connector at radio. |
| | Element LX | 03 - 09 | DF - HON | PA11 HON | included | cd button | Connector at radio. |
| | Accord | 03 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | Accord | 98 - 02 | DF - HON | PA11 HON | included | cd button | 14-pin connector at radio. |
| | Accord | 94 - 97 | DF - HON | PA11 HON | included | cd button | 8-pin din connector at radio. |
| | Civic | 06 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display, all radio must have SAT or XM button. |
| | Civic | 99 - 05 | DF - HON | PA11 HON | included | cd button | Existing slave OEM CDP must be disconnected. |
| | Civic | 94 - 98 | DF - HON | PA11 HON | included | cd button | Existing slave OEM CDP must be disconnected. |
| | CRV | 05 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | Odyssey | 05 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | CRV/Odyssey/Prelude | 99 - 04 | DF - HON | PA11 HON | included | cd button | 14-pin connector at radio. |
| | | 95 - 98 | DF - HON | PA11 HON | included | cd button | 8-pin din connector at radio. |
| | Fit | 07 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | Passport | 98 - 02 | DF - TOY | PA15 TOY | included | cd button | Connector at radio. |
| | Pilot | 06 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | Pilot | 03 - 05 | DF - HON | PA11 HON | included | cd button | Except vehicles with GPS or Video Systems. |
| | Ridgeline | 06 - 09 | N/A | PA15 HON2 | included | all models | For TEXT display radio must have SAT or XM button. |
| | S2000 | 04 - 07 | N/A | PA15 HON2 | included | all models | Connector at radio. |
| **NOTE: PA11-HON is not compatible with vehicles with in-dash cd changer. External CD changer must be disconnected.** | | | | | | | |
| **NOTE: PA15-HON2, Compatible with all radios including -IN DASH 6 Disc, radios with Factory Nav.TEXT display - all radio must have SAT or XM button.** | | | | | | | |
| Hummer | H2/SUT | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | H2/SUT | 03 - 07 | | PA11 - GM* | included | band | *Connector at radio. Use PA11-VETTE if the vehicle has XM and connect it @ XM. |
| | H3 | 06 - 09 | | PA11 - GM* | included | band | *Connector at radio. Use PA11-VETTE if the vehicle has XM and connect it @ XM. |
| **NOTE: PA11 NIS is NOT compatible with the vehicles that have Satellite radio or Bluetooth.** | | | | | | | |
| Infiniti | G35 Coupe/Sedan | 04 - 07 | | PA11 NIS | included | CDC | NOT compatible with vehicles that have SAT tuner. |
| | FX35 | | N/A | N/A | | | |
| | QX56 | | N/A | N/A | | | |
| | All Models | 99 - 01 | PA11 NIS | PA11 NIS | included | cd/chg | Connector is behind the radio |
| Isuzu | Amigo, Rodeo, Trooper | 98 - 03 | DF - TOY | PA15 TOY | included | disc | Radio must have DISC button |
| | Ascender | 04 - 05 | SVG 707 | PA11 GM | included | band | *SCD-G7i will not work with vehicles with XM Turner |
| Jeep | Commander | 2006 | | n/a | | | |
| | G. Cherokee | 05 - 06 | | na | | | |
| | G. Cherokee | 02 - 04 | DF CHR | PA11 CHR | included | mode button | Radio must have MODE button. 10-pin square plug at radio. |
| | | 99 - 01 | DF CHR | PA11 CHR | included | cd-c button | Radio must have CD-C button. 8-pin din connector at radio. |
| | | 95 - 98 | *DF HON | *PA11 HON | CDL CJ | mode/cd | For rectangular AM/FM/TAPE radio with MODE/CD |
| | Liberty | 02 - 06 | DF CHR | PA11 CHR | included | mode button | Radio must have MODE button. 10-pin square plug at radio. |
| | Wrangler | 03 - 06 | DF CHR | PA11 CHR | included | mode button | Radio must have MODE button. 10-pin square plug at radio. |
| ***Note: DR-CHR & PA11-CHR are not compatible with the vehicles that have GPS, Satellite Radio, DVD, or in dash cd changer. Call Tech for update info.*** | | | | | | | |
| Lexus | ***Note: All Gen5 Nav. Radio use PA20 TOY and use the MP3 setting*** | | | | | | |
| | ES300*/330/350 | 03 - 09 | N/A | PA15/20-TOY | included | all models | Connect @ radio. *ES300 may need CAS-LEX cable. |
| | GX470 | 04 - 09 | N/A | PA15/20-TOY | included | all models | Connect @ radio |
| | GS300/350/430/450H | 05 - 09 | N/A | PA15/20-TOY | included | all models | Connect @ radio |
| | IS250/300/350 | 01 - 09* | N/A | PA15/20-TOY | included | all models | *01-03 may need CAS-LEX harness. Connect @ radio |
| | LS 430 | 01 - 06 | N/A | PA15/20-TOY | included | all models | *01-03 may need CAS-LEX harness. Connect @ radio |
| | LS 460 | 07 - 09 | N/A | PA20-TOY | included | all models | Connect @ radio |
| | LX470 | 01 - 08* | N/A | PA15/20-TOY | included | all models | *01-03 may need CAS-LEX harness. Connect @ radio |
| | LX570 | 2009 | N/A | PA20-TOY | included | all models | Connect @ radio |
| | RX300 | 00 - 03 | N/A | PA15-TOY | Not included* | Nav | *Required CAS-LEX cable. Connect @ radio. |
| | | | | | | Non Nav | *Required CAS-TLC cable. Vehicle must have 6 CD changer (which must be disconnected). Connect CAS-TLC to CDC |
| | RX330/350/400H | 04 - 09 | N/A | PA15/20-TOY | included | all models | Connect @ radio. |
| **TEXT display is available on radios with TEXT/TITLE button only. Some 01-03 models may require CAS-LEX cable** | | | | | | | |

# USA SPEC Application Guide

| Make | Model | Year | AUX Interface | iPod Interface | Cable for AUX/iPod | Visual ID | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
|---|---|---|---|---|---|---|---|
| Mercedes | C, E Class | 94 - 98 | DF HON | PA11 HON | CB PM4 | all models | 10-pin connector in right-rear trunk behind quarter panel. |
| | SL | 94 - 98 | DF HON | PA11 HON | CB PM4 | all models | 10-pin connector in left-rear trunk behind quarter panel. |
| | S-class 4Dr | 94 - 99 | DF HON | PA11 HON | CB PM4 | all models | 10-pin connector in left-rear trunk behind quarter panel. |
| ***Note: PA11 NIS is not compatible with vehicles that have Satellite radio, DVD ,external cd changer or Bluetooth.*** | | | | | | | |
| Nissan | Altima / Frontier | 99 - 01 | | PA11 NIS | included | cd/chg | For double din radio with CD/ CHG button only. |
| | Maxima | 99 - 01 | | PA11 NIS | included | cd/chg | For double din radio with CD/ CHG button only. |
| | Maxima | 02 - 06 | | PA11 NIS | included | cd/chg | |
| | Murano | 05 - 06 | | PA11 NIS | included | CDC control | Radio must have cd changer control. |
| | Pathfinder | 99 - 01 | | PA11 NIS | included | cd/chg | |
| | 350Z | 04 - 07 | | PA11 NIS | included | cd | Connector at radio. |
| | Quest | 99 - 02* | DF-FORD20 | PA11 FORD1 | included | cd button | 01-02: Console mounted monitor use CDL-F20 cable |
| | | 96 - 98 | DF-FORD16 | PA11 FORD2 | included | cd button | Connector at radio. |
| | Sentra | 03 - 06 | | PA11 NIS | included | cdc | |
| | Sentra | 99 - 00 | n/a | PA11 NIS | included | cd/chg | For double din radio with CD/ CHG button only. |
| | Xtera | 99 - 01 | | PA11 NIS | included | cd/chg | Not compatible with Rockford radio |
| Pontiac | Bonneville | 97 - 99 | n/a | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave unit must be disconnected |
| | Firebird / Grand Prix | 00 - 02 | n/a | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave unit must be disconnected |
| | | 97 - 99 | n/a | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave unit must be disconnected |
| | Grand Prix | 2005 | | PA11 GM | included | all models | connector behind radio |
| | *Grand Prix* | *2006* | | *n/a* | | | |
| | Grand Am | 97 - 00 | n/a | PA11 GM45 | included | aux button | AM/FM/TAPE radio with AUX only. Slave unit must be disconnected |
| | G5 | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL11 needed if the vehicle DOES NOT have XM Receiver. |
| | Vibe | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Vibe | 05 - 06 | | PA11 GM | included | band | |
| | Torrent | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL29 needed if the vehicle DOES NOT have XM Receiver. |
| | Solistice | 08 - 09 | | PA20 GM | included* | all models | TEXT. * Additional cable P/N: CB-GL11 needed if the vehicle DOES NOT have XM Receiver. |
| Scion* | xA,xB | 04 - 08 | DF TOY | PA15 TOY | included | all models | Connector behind radio. |
| | tC | 05 - 08 | DF TOY | PA15 TOY | included | all models | Connector behind radio. |
| **TEXT display is available on Toyota,Scion and Lexus radios with TEXT button only** | | | | | | | |
| Toyota | Mr2 / Celica | 98 - 06 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | 4 Runner* | 98 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. *If the vehicle (06 and earlier) has RSE, connect PA15/20-TOY @ ECU. |
| | Avalon | 98 - 09* | DF TOY | PA15/20-TOY | included | all models | *PA15-TOY will work as AUX for NAV radio. |
| | Camry | 98 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | Solara | 98 - 09* | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. *Some radios will not display TEXT. |
| | Corolla / Echo | 98 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | FJ Cruiser | 07 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | Highlander* | 01 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. *If the vehicle has RSE, connect PA15-TOY @ ECU. |
| | Land Cruiser* | 98 - 09 | DF TOY | PA15/20-TOY | included | all models | 01-03 Land Cruiser requires CAS-TLC cable (must order separately) |
| | Matrix | 03 - 04 | N/A | N/A | included | all models | Connect @ radio. |
| | Matrix | 05 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | Prius | 04 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | Rav4 | 98 - 09 | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. |
| | Sequoia / Tundra* | 98 - 09* | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. *If the vehicle has RSE, connect PA15/20-TOY @ ECU. |
| | Sienna* | 98 - 09* | DF TOY | PA15/20-TOY | included | all models | Connect @ radio. *If the vehicle has RSE, connect PA15/20-TOY @ ECU. 98-02 Sienna with steering wheel control requires CAS-TLC cable (must order separately) |
| | Tacoma | 98 - 09 | DF TOY | PA15 TOY | included | all models | Connect @ radio. |
| | Yaris | 07 - 09 | DF TOY | PA15 TOY | included | all models | Connect @ radio. |
| **Use PA20-TOY for 06-09 vehicles with GEN5 (plays MP3/WMA) FACTTORY Nav Radio & on all Prius with MP3 player radio. TEXT display is available on radios with TEXT/TITLE button only** | | | | | | | |
| Volkswagen | Cabrio | 98 - 04 | DF VW | PA11 VW6 | included | all models | One brown wire has to be grounded from OEM CD changer plug. |
| | Beetle | 98 - 03 | DF VW | PA11 VW6 | included | all models | Pre-wired at left-rear trunk behind small black plastic cover. |
| | Beetle/ Convertible | 03 - 07 | DF VW | PA11 VW6 | included | all models | Connector behind the radio. |
| | EuroVan | 01 - 04 | DF VW | PA11 VW6 | included | all models | Connector behind the radio. |
| | Golf/GTi | 98 - 05 | DF VW | PA11 VW6 | included | all models | Pre-wired at left-rear trunk behind storage door. |
| | Rabbit/GTi | 06 - 08 | N/A | PA11 VW6 | included | all models | Connector at radio |
| | Jetta | 98 - 05* | DF VW | PA11 VW6 | included | all models | Pre-wired at left-rear trunk behind storage door. |
| | Jetta | 051/2-08 | N/A | PA11 VW6 | included | all models | Connector at radio |
| | Passat | 98 - 05 | DF VW | PA11 VW6 | included | all models | Pre-wired at left-rear trunk behind storage door. |
| | Passat | 06 - 08 | N/A | PA11 VW6 | included | all models | Connector at radio |
| | Touareg | 04 - 07 | DF VW | PA11 VW6 | included | all models | Pre-wired -SCD-VW44E will not fit inside the compartment. |
| **Connect PA11-VW6 at radio, connect SCD-VW44E at pre-wired CDC plug.** | | | | | | | |
| **Some 98-99 cars with BOSE or PREMIER radios with13-pin din plug in trunk are not compatible with SCD-VW44E nor DF/PA11- VW** | | | | | | | |
| Volvo | All Models | 94 - 00 | DF HON | PA11 HON | CDL VOL | all models | Except S80. CDL VOL: Yellow wire is B+,red wire is Acc.+ |
| | C70 | 01 - 06 | DF HON | PA11 HON | CDL VOL | all models | CDL-VOL: Yellow wire is B+, red wire is ACC+ |
| | S40/V40 | 01 - 04* | n/a | PA11 VOL | included | all models | *Connector behind radio. Do not use OEM pre-wired cable. |
| | S60/S70/S80 | 01 - 07 | n/a | PA11 VOL | included | all models | *Connector behind radio. Do not use OEM pre-wired cable. |
| | XC70/V70 | 01 - 07* | n/a | PA11 VOL | included | all models | *Connector behind radio. Do not use OEM pre-wired cable. |
| **PA11-VOL is compatible with Nav radio. Requires CAS-VOL_NAV cable** | | | | | | | |